



THE WORLD'S LEADING MANUFACTURER OF LABEL DISPENSERS, REWINDERS, UNWINDERS & COUNTING SOLUTIONS



QUICK-CHUCK


labelmate.com



Quick-Loading Core Chucks

LABELMATE's precision, maintenance-free "Quick Chuck"™ Core Chucks support the mounting or removing a roll of labels on your rewinder or unwinder in seconds. For applications with heavy label rolls, regular roll changes and for holding multiple cores during slitting operations.

- ✓ Fast loading & unloading
- ✓ 5 diameters available
- ✓ 3 widths, up to 270mm
- ✓ Fit onto 15.85mm diameter motor shaft Limited Warranty




P/N	MODEL	DIAMETER	WIDTH
LMX479	C-38170	38 mm	170 mm
LMX480	C-40170	40 mm	170 mm
LMX481	C-44170	44 mm	170 mm
LMX482	C-70170	70 mm	170 mm
LMX483	C-76170	76 mm	170 mm
LMX484	C-76220	76 mm	220 mm
LMX485	C-76270	76 mm	270 mm
LMX506	220mm outer Flange for "Quick-Chuck" 76mm core diameter.		
LMX144	220mm inner Flange for "Quick-Chuck" 70 & 76 core diameter.		
LMX507	220mm inner Flange for "Quick-Chuck" 38, 40 & 44mm core diameter.		
LMX508	300mm outer Flange for "Quick-Chuck" 76mm core diameter.		
LMX509	300mm inner Flange for "Quick-Chuck" 70 & 76 core diameter.		
LMX510	400mm outer Flange for "Quick-Chuck" 76mm core diameter.		
LMX511	400mm outer Flange for "Quick-Chuck" 76mm core diameter.		
LMX512	400mm inner Flange "Quick-Chuck" 76mm core diameter.		
LMX513	400mm inner Flange for "Quick-Chuck" 38, 40 & 44mm core diameter.		

HOW TO:

- To use a Quick-Chuck, just slide your label roll over the Chuck and turn the convenient lock knob. Instantly your roll is locked in place. To remove the roll, just give the lock knob a quick turn to the left and pull the roll off your machine !



Your local partner:



+32 2 375 69 60

brussels@labelmate.com

Bergensesteenweg 78

1651 Lot (Belgium)

www.labelmate.com